

ISE 315: Engineering Statistics

Supplementary Material: Reading Z-Tables & Excel Formulas

Instructor: Mansur M. Arief, PhD
Industrial and Systems Engineering, KFUPM

Office: 22-219 — Email: mansur.arief@kfupm.edu.sa

Based on Montgomery & Runger, Applied Statistics and Probability for Engineers, 6th Ed.

Overview

- Part 1: Reading the Standard Normal (Z) Table
 - Finding $P(Z \leq z)$ from the table
 - Finding z from a given probability
- Part 2: Excel Formulas for Normal Distribution
 - `NORM.S.DIST` and `NORM.S.INV` for Z
 - `NORM.DIST` and `NORM.INV` for $\bar{X}$
- Part 3: Examples
 - Z-score examples (from Lecture 2)
 - Non-standardized $\bar{X}$ example
 - Confidence intervals at 80%, 95%, 99.9999%
- Part 4: Practice Problems

Part 1

Reading the Standard Normal (Z) Table

Structure of the Z-Table

- The Z-table gives $\Phi(z) = P(Z \leq z)$ for $Z \sim N(0, 1)$
- Rows: first digit and first decimal of z (e.g., 1.9)
- Columns: second decimal of z (e.g., 0.06)

z	0.00	0.01	0.02	...	0.05	0.06	...
...	...	...	...	...	...	...	...
1.6	0.9452	0.9463	0.9474	...	0.9505	0.9515	...
...	...	...	...	...	...	...	...
1.9	0.9713	0.9719	0.9726	...	0.9744	0.9750	...
2.0	0.9772	0.9778	0.9783	...	0.9798	0.9803	...
...	...	...	...	...	...	...	...


Example: $\Phi(1.96) = P(Z \leq 1.96) = 0.9750$

Task 1: Finding Probability from Z-Score

Given: A z-score, find $P(Z \leq z)$, $P(Z > z)$, or $P(a < Z < b)$

Key relationships:

- $P(Z \leq z) = \Phi(z)$ (read directly from table)
- $P(Z > z) = 1 - \Phi(z)$ (complement)
- $P(Z < -z) = 1 - \Phi(z)$ (symmetry)
- $P(a < Z < b) = \Phi(b) - \Phi(a)$ (subtraction)
- $P(|Z| < z) = 2\Phi(z) - 1$ (both tails)



Task 2: Finding Z-Score from Probability (Inverse)

Given: A probability p , find z such that $P(Z \leq z) = p$

Method: Search *inside* the table for p , then read row + column headers

Example: Find z such that $P(Z \leq z) = 0.975$

z	0.00	...	0.05	0.06	0.07	...
...	...	...	...	...	...	...
1.8	0.9641	...	0.9678	0.9686	0.9693	...
1.9	0.9713	...	0.9744	0.9750	0.9756	...
2.0	0.9772	...	0.9798	0.9803	0.9808	...
...	...	...	...	...	...	...

Common Critical Values

Conf. Level	α	Two-sided (CI)		One-sided	
		$\Phi(z_{\alpha/2})$	$z_{\alpha/2}$	$\Phi(z_{\alpha})$	z_{α}
90%	0.10	0.95	1.645	0.90	1.282
95%	0.05	0.975	1.960	0.95	1.645
99%	0.01	0.995	2.576	0.99	2.326

How to read this table:

- **Two-sided:** Use $z_{\alpha/2}$ (e.g., 95% CI $\Rightarrow \alpha = 0.05 \Rightarrow z_{0.025} = 1.96$)
- **One-sided:** Use z_{α} (e.g., 95% lower bound $\Rightarrow \alpha = 0.05 \Rightarrow z_{0.05} = 1.645$)

Part 2

Excel Formulas for Normal Distribution

Excel Functions for Normal Distribution

For Standard Normal $Z \sim N(0, 1)$:

- `=NORM.S.DIST(z, TRUE)` $\Rightarrow$ Returns $\Phi(z) = P(Z \leq z)$
- `=NORM.S.INV(p)` $\Rightarrow$ Returns z such that $P(Z \leq z) = p$

For General Normal $X \sim N(\mu, \sigma)$:

- `=NORM.DIST(x,  $\mu$ ,  $\sigma$ , TRUE)` $\Rightarrow$ Returns $P(X \leq x)$
- `=NORM.INV(p,  $\mu$ ,  $\sigma$ )` $\Rightarrow$ Returns x such that $P(X \leq x) = p$

Important: The TRUE parameter gives CDF/cumulative probability.

FALSE gives the PDF—rarely needed for our class.

NORM uses standard deviation σ , NOT variance σ^2 .

Excel Formula Quick Reference

Task	Standard Normal	General Normal
$P(Z \leq z)$ or $P(X \leq x)$	NORM.S.DIST(z,TRUE)	NORM.DIST(x, μ , σ ,TRUE)
$P(Z > z)$ or $P(X > x)$	1-NORM.S.DIST(z,TRUE)	1-NORM.DIST(x, μ , σ ,TRUE)
Find z given $P(Z \leq z) = p$	NORM.S.INV(p)	NORM.INV(p, μ , σ)

For Sampling Distribution of $\bar{X}$:

- Use NORM.DIST with $\mu_{\bar{X}} = \mu$ and $\sigma_{\bar{X}} = \sigma/\sqrt{n}$
- Example: =NORM.DIST(0.6, 0.5, 0.091, TRUE)

Part 3

Examples

From Lecture 2: Population $X_i \sim \text{Uniform}(0, 1)$, sample size $n = 10$.
Find $P(\bar{X} > 0.6)$.

Example 1: Standardized Z-Score

Step 1: Find population parameters

- $\mu = 0.5, \sigma^2 = 1/12 \Rightarrow \sigma = 0.289$

Step 2: Find sampling distribution of $\bar{X}$

- $\mu_{\bar{X}} = \mu = 0.5$
- $\sigma_{\bar{X}} = \frac{\sigma}{\sqrt{n}} = \frac{0.289}{\sqrt{10}} = 0.091$

Step 3: Standardize $Z = \frac{\bar{X} - \mu_{\bar{X}}}{\sigma_{\bar{X}}} = \frac{0.6 - 0.5}{0.091} = \boxed{1.10}$

Step 4: Find $P(\bar{X} > 0.6) = P(Z > 1.10) = 1 - \Phi(1.10)$ (use table or Excel)

Example 1: Using Z-Table for $\Phi(1.10)$

Reading the Z-table for $z = 1.10$:

- Row: 1.1, Column: 0.00

z	0.00	0.01	0.02	...
1.0	0.8413	0.8438	0.8461	...
1.1	0.8643	0.8665	0.8686	...
1.2	0.8849	0.8869	0.8888	...

Excel alternative:

- =NORM.S.DIST(1.10, TRUE) returns 0.8643

Answer: $P(\bar{X} > 0.6) = P(Z > 1.10) = 1 - \Phi(1.10) = 1 - 0.8643 = \boxed{0.1357}$

From Lecture 4: Two catalysts with $n_1 = 50$, $\sigma_1 = 4$ and $n_2 = 45$, $\sigma_2 = 5$. Find $P(|(\bar{X}_1 - \bar{X}_2) - (\mu_1 - \mu_2)| < 1.5)$.

Example 2: Difference of Means Z-Score

Step 1: Find standard error of $\bar{X}_1 - \bar{X}_2$

$$SE = \sqrt{\frac{\sigma_1^2}{n_1} + \frac{\sigma_2^2}{n_2}} = \sqrt{\frac{16}{50} + \frac{25}{45}} = \sqrt{0.876} = 0.936$$

Step 2: Standardize $Z = \frac{(\bar{X}_1 - \bar{X}_2) - (\mu_1 - \mu_2)}{SE} \Rightarrow |Z| < \frac{1.5}{0.936} = \boxed{1.60}$

Step 3: Find probability

$$P(|Z| < 1.60) = P(-1.60 < Z < 1.60) = \Phi(1.60) - \Phi(-1.60)$$

Example 2: Z-Table

Z-Table lookup for $z = 1.60$:

z	0.00	0.01	0.02	0.03	0.04	0.05
1.5	0.9332	0.9345	0.9357	0.9370	0.9382	0.9394
1.6	0.9452	0.9463	0.9474	0.9484	0.9495	0.9505
1.7	0.9554	0.9564	0.9573	0.9582	0.9591	0.9599

- Row: 1.6, Column: 0.00 $\Rightarrow \Phi(1.60) = 0.9452$
- By symmetry: $\Phi(-1.60) = 1 - \Phi(1.60) = 1 - 0.9452 = 0.0548$

Answer: $P(|Z| < 1.60) = \Phi(1.60) - \Phi(-1.60) = 0.9452 - 0.0548 = \boxed{0.8904}$

Drilling mud viscosity: $\mu = 48$ cp, $\sigma = 6$ cp, $n = 36$. Find $P(47 < \bar{X} < 50)$ using Excel (without standardizing).

Example 3: Non-Standardized $\bar{X}$ in Excel

Step 1: Identify sampling distribution parameters

- $\mu_{\bar{X}} = \mu = 48 \quad \sigma_{\bar{X}} = \frac{\sigma}{\sqrt{n}} = \frac{6}{\sqrt{36}} = 1$

Step 2: Use NORM.DIST directly (no need to standardize!)

$$P(47 < \bar{X} < 50) = P(\bar{X} < 50) - P(\bar{X} < 47)$$

Excel formula:

- `=NORM.DIST(x,  $\mu$ ,  $\sigma$ , TRUE) - NORM.DIST(x,  $\mu$ ,  $\sigma$ , TRUE)`
- `=NORM.DIST(50, 48, 1, TRUE) - NORM.DIST(47, 48, 1, TRUE)`
- `= 0.9772 - 0.1587 = 0.8186`

Pipeline wall thickness: $n = 25$, $\bar{x} = 0.2731$ in, $\sigma = 0.02$ in. Find CI at 80%, 95%, and 99.9999% confidence.

Example 4: Confidence Intervals at Different Levels

Step 1: Calculate standard error (same for all)

$$SE = \frac{\sigma}{\sqrt{n}} = \frac{0.02}{\sqrt{25}} = 0.004$$

Step 2: Find critical values

- 80% CI: $\alpha = 0.20 \Rightarrow z_{0.10} = 1.282$
- 95% CI: $\alpha = 0.05 \Rightarrow z_{0.025} = 1.960$
- 99.9999% CI: $\alpha = 0.000001 \Rightarrow z = ?$

Excel for 99.9999%: =NORM.S.INV(0.9999995) returns 4.8916


Example 4: Results Comparison

CI Formula: $\bar{x} \pm E = \bar{x} \pm z_{\alpha/2} \times SE = 0.2731 \pm z_{\alpha/2} \times 0.004$

Conf. Level	$z_{\alpha/2}$	E	95% CI
80%	1.282	$1.282 \times 0.004 = 0.00513$	(0.2680, 0.2782)
95%	1.960	$1.960 \times 0.004 = 0.00784$	(0.2653, 0.2809)
99.9999%	4.892	$4.892 \times 0.004 = 0.01957$	(0.2535, 0.2927)

- 80% CI is narrow but we're less confident
- 99.9999% CI is very wide but we're almost certain μ is inside

Visualizing Different Confidence Levels



Trade-off: Higher confidence = Wider interval

Practice Problems (Z-table and Excel)

1. Find $P(Z < 2.33)$ and $P(Z > -1.5) \Rightarrow 0.9901, 0.9332$
2. Find z such that $P(Z > z) = 0.01 \Rightarrow 2.326$
3. If $X \sim N(100, 15^2)$ and $n = 25$, find $P(\bar{X} > 105) \Rightarrow 0.0478$
4. Construct 90%, 95%, and 99.99% CIs for μ given:
 $n = 40, \bar{x} = 72.5, \sigma = 8$
 $\Rightarrow (70.42, 74.58), (70.02, 74.98), (69.58, 75.42)$